



Schema di connessione per caldaie CLP 30 - CLP 45 - CLP 60 - CLP 80

CLP 30 / CLP 45 / CLP 60 / CLP 80




Schemi di connessione


Connection diagrams - Anschlusspläne - Schémas de connexion - Diagramas de conexión



Schema di connessione impianto a vaso aperto (sotto i 2 bar)



Schema di connessione impianto a vaso aperto (sopra i 2 bar con potenza fino a 100 kW)







Schemi di connessione

Connection diagrams - Anschlusspläne - Schémas de connexion - Diagramas de conexión

Schema di connessione impianto a vaso aperto (sopra i 2 bar con potenze superiori a 100 kW)



Schema di connessione impianto a vaso chiuso (con potenze inferiori a 100 kW)




Schemi di connessione


Connection diagrams - Anschlusspläne - Schémas de connexion - Diagramas de conexión



Schema di connessione impianto a vaso chiuso (con potenze superiori a 100 kW)



Schema di installazione canna fumaria



Schemi di connessione
(Connection diagrams)